

SPARE PARTS LIST

MODEL NO. 1923H

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
001	911123-8	PAN HEAD SCREW M4X14	2	
002	410828-2	REAR COVER 1923H	1	
003	816601-2	SCALE LABEL 1923H	1	
004	271231-0	KNOB 46 1923B/1901/N1923BD	1	
005	941251-5	FLAT WASHER 10	1	
006	*****	*****	***	*****
007	682502-4	CORD GUARD 8-85 3707/N1923B	1	
008	*****	*****	***	*****
009	687001-1	STRAIN RELIEF 4157KB/6820V	1	
010	911133-5	PAN HEAD SCREW M4X18	2	
011	855640-7	NAME PLATE 1923H	1	
012	645200-1	NOISE SUPPRESSOR LS0714 only	1	
013	*****	*****	***	*****
014	911224-2	PAN HEAD SCREW M5X16	2	
015	*****	*****	***	*****
016	263014-2	RUBBER PIN 4 SR2600/N1923BD/HR	1	
017	211031-6	BALL BEARING 608LLB (608VV) 67	1	
018	681613-2	INSULATION WASHER 806 HR1800	1	
019	*****	*****	***	*****
020	*****	*****	***	*****
021	911158-9	PAN HEAD SCREW M4X30	3	
022	410827-4	BAFFLE PLATE 1923H	1	
023	241836-0	FAN 65 1923H	1	
024	211066-7	BALL BEARING 6200LLB/9402	1	
025	*****	*****	***	*****
026	911148-2	PAN HEAD SCREW M4X25	6	
027	263002-9	RUBBER PIN 4/9402/HR160DWH/903	1	
028	211067-5	BALL BEARING 6200ZZ	1	
029	263002-9	RUBBER PIN 4/9402/HR160DWH/903	1	
030	161103-6	DRUM 1923H	1	
031	793322-2	T.C.T. MINI PLANER BLADE 82	1	
032	342430-2	ADJUST PLATE 1923B/1901	2	
033	251246-3	+ PAN HEAD SCREW M4X5	4	
034	961003-8	RETAINING RING S-7	1	
035	*****	*****	***	*****
036	285637-6	BEARING RETAINER 7-21 1923B/N	1	
037	911226-8	PAN HEAD SCREW M5X18	1	
038	951054-9	SPRING PIN 3-10	1	
039	165025-2	DRUM HOLDER N1923BD	1	
040	343948-6	DRUM COVER N1923BD	1	
041	231504-3	TORSION SPRING 10 1051D/N1923B	1	
042	265006-7	+ SCREW M5X25	1	
043	924206-5	WING BOLT M5X10	1	
044	942101-7	SPRING WASHER 5	1	
045	941101-4	FLAT WASHER 5	1	
046	342390-8	DEPTH GUIDE 1125 1923B N1923BD	1	
047	251812-6	SCREW M5X10	1	
048	157661-8	MAIN FRAME 1923H INC. 16	1	
049	345001-4	DRUM PLATE 1923B (2PC/SET) N1	1	
050	251609-3	HEX. FLANGE HEAD BOLT M6X17	6	
051	231004-3	COMPRESSION SPRING 18 1125/23B	1	
052	421007-7	RUBBER PACKING 1923B/1901/N192	1	
053	*****	*****	***	*****
054	911226-8	PAN HEAD SCREW M5X18	4	
055	312023-9	BASE 1923B/1901/N1923BD	1	
056	152371-2	BRACKET 1923H INC. 27,29	1	
057	*****	*****	***	*****
058	225071-8	POLY V-BELT 1901/1902	1	
059	410826-6	BELT COVER 1923H	1	

SPARE PARTS LIST

MODEL NO. 1923H

ITEM	PART NO.	DESCRIPTION	QTY	NOTE
060	911133-5	PAN HEAD SCREW M4X18	1	
401	911228-4	PAN HEAD SCREW M5X18	2	
402	411086-3	*BLADE GAUGE ASSY	1	
403	123062-2	BLADE GAUGE ASSY 1125/1901 INC. 401,402	1	
404	*****	*****	***	*****
405	782209-3	SOCKET WRENCH 9 1125 5000SB	1	
407	911138-5	PAN HEAD SCREW M4X20	1	
903	343433-9	SET PLATE F/MINI BLADE	2	
913	192080-1	NOZZLE FOR VACUUM CLEANER 1923	1	
915	253807-5	FLAT WASHER 5	1	
917	343947-8	SLIDE PLATE N1923BD	1	
922	410889-2	NOZZLE FOR DUST BAG 1923H	1	
923	911138-5	PAN HEAD SCREW M4X20	1	
924	166010-8	*DUST BAG 1923H	1	
925	213601-7	O RING 50 1923B/N1923BD	1	

SERVICE DRAWING

MODEL NO. 1923H

