

SPARE PARTS LIST

MODEL NO. 6339D

| ITEM | PART NO. | DESCRIPTION | QTY | NOTE |
|------|----------|--------------------------------|-----|-------|
| 001 | 860954-1 | NAME PLATE 6339D | 1 | |
| 002 | ***** | ***** | *** | ***** |
| 003 | 266130-9 | TAPPING SCREW BIND PT 3X16 | 9 | |
| 004 | 344391-2 | BIT HOLDER 6313DW/8413D-43D | 1 | |
| 005 | 125261-2 | SPEED CHANGE LEVER ASSY | 1 | |
| 006 | 418753-1 | F/R CHANGE LEVER 6319/6339/634 | 1 | |
| 008 | 650559-3 | SWITCH C3LA-2A-ED 6319/6349/63 | 1 | |
| 009 | 687085-9 | HOLDER 6313DW/8413D-43D/UB120D | 1 | |
| 010 | 654168-0 | SPRING TERMIANL (+) 6313DW/841 | 1 | |
| 011 | 654169-8 | SPRING TERMINAL (-) 6313D/SC16 | 1 | |
| 012 | 251464-3 | - FLAT HEAD SCREW M6X22 | 1 | |
| 013 | 763188-4 | KEYLESS DRILL CHUCK 13 | 1 | |
| 014 | 253798-0 | FLAT WASHER 13 | 1 | |
| 015 | 125262-0 | GEAR ASSY 6319/6339/6349 | 1 | |
| 016 | 638376-1 | YOKE UNIT 6319/6339/6349D | 1 | |
| 017 | 629829-1 | ARMATURE 6339 | 1 | |
| 018 | 638375-3 | ENDBELL COMP 6319/6339/6349 | 1 | |
| 019 | 191971-3 | CARBON BRUSH SET CB-430 | 1 | |
| 020 | 643929-3 | HOLDER CAP 6313DW/8413D/8433D | 2 | |
| 021 | 266282-6 | TAPPING SCREW ST3X10 | 1 | |
| 022 | 689136-4 | FELT SPACER 6319/6339/6349 | 1 | |
| 023 | 266045-0 | TAPPING SCREW 4X20 | 4 | |
| 024 | ***** | ***** | *** | ***** |
| 025 | ***** | ***** | *** | ***** |
| 026 | 819001-5 | MAKITA LABEL | 1 | |
| 028 | 344391-2 | BIT HOLDER 6313DW/8413D-43D | 1 | |
| A01 | ***** | ***** | *** | ***** |
| A02 | ***** | ***** | *** | ***** |
| A04 | ***** | ***** | *** | ***** |
| A05 | 784637-8 | + - BIT 2-45 | 2 | |
| A06 | 824626-2 | PLASTIC CASE 8433&43D/6316D | 1 | |
| A07 | 192752-8 | ML140 RECHARGEABLE FLASHLIGHT | 1 | |
| A08 | 345261-8 | HOOK BUTTON ML702/902/903/180 | 2 | |
| A09 | 417926-3 | STRAP ML702/902/903/180 | 1 | |

SERVICE DRAWING

MODEL NO. 6339D

