


9. VI25 – PARTS LIST

Item	Part No	Description	Qty
1	VT-1861	Shaft key	2
2	VT-1774	End plate	2
3	VT-1775	Shaft	1
4	VT-1783	Vane	1
5	VT-1776	Rotor	1
6	VT-1769	Housing	1
7	VT-2524	O ring	3
8	VT-1902	Nosepiece (steel)	1
8a	VT-16100	Nosepiece (rubber)	1
9	VT-1773	Rear closure plate	1
10	VT-2525	O ring	1
11	VT-1903	Air exhaust body	1
12	VT-1779	Nipple	1
13	VT-1785	Sleeve	1
14	VT-1777	Rear body	1
15	VT-1778	Sleeve	1
16	VT-1784	Exhaust hose	1
17	VT-16040	Exhaust body	1
18	VT-16039	Inlet hose connector	1
20	VT-16085	Hose clip	1
21	VT-2526	Hose clip	1
30	VT-16120	Steel handle comp.	1
31	VT-81	Rubber gland	1
32	VT-156	Gauze filter	1
33	VT-2512	Q. R. coupling	1
34	VT-2273	O ring	2
35	VT-2261	Handle shaft	1
36	VT-2262	Guide pin	1
37	VT-2260	Twist grip	1
38	VT-16042	Adapter	1
39	VT-10270/S	Lubricator complete	1
40	VT-10289/S	Lubricator tube	1
41	VT-10273	Rubber ring	1
42	VT-10271/S	Lubricator body	1
43	VT-2524L	O ring	1
44	VT-2265	Oil filler screw	1
45	VT-2525	O ring	1
46	VT-2521	Felt	7
47	VT-2521	Bleed wire	1



10. V635 – V675 PARTS LIST

Item	Part Number					Description	Qty
	V635	V645	V655	V665	V675		
1	VT-2631	VT-5551	VT-1463	VT-16265	VT-3551	Nosepiece	1
1a	VT-5994	VT-5550	VT-1577	VT-19145	VT-3611	Rubber nosepiece	1
2	VT-779	VT-1808	VT-2126	VT-16288	VT-2330	O ring	2
3	VT-16200	VT-16210	VT-16220	VT-16260	VT-16230	Front closure plate	1
4	VT-16201	VT-16211	VT-16221	VT-16261	VT-16231	Housing	1
5	VT-16202	VT-16212	VT-16222	VT-16262	VT-16232	Rotor	1
6	VT-16203	VT-16213	VT-16223	VT-16263	VT-16233	Vane	1
7	VT-16204	VT-16214	VT-16224	VT-16264	VT-16234	Rear closure plate	1
8	VT-16134	VT-7704	VT-7663	VT-16267	VT-7688	Locking ring	1
9	-	VT-5521	VT-16225	VT-16225	VT-16235	Inlet hose connector	1
10	VT-137	VT-137	VT-5456	VT-5456	VT-5211	Inlet hose clip	2
11	VT-788	VT-788	VT-1583	VT-1583	VT-540	Inlet hose	*
12	VT-2622	VT-7701	VT-1576	VT-16266	VT-3553	Rear Body	1
13	VT-2623	VT-1730	VT-1582	VT-1582	VT-1604	Hose sleeve	1
14	-	-	VT-1478	VT-1478	VT-1479	Hose protection sleeve	1
15	VT-2021	VT-7983	VT-1584	VT-1584	VT-541	Exhaust hose	*
16	VT-3679	VT-2392	VT-75	VT-75	VT-76	Exhaust hose clip	1
17	VT-10225	VT-10225	VT-10223	VT-10223	VT-10222	Exhaust body	1
18	VT-10588	VT-10588	VT-10221	VT-10221	VT-10219	Inlet hose connector	1
30	VT-16120	VT-16120	VT-16120	VT-16120	VT-16120	Steel handle complete	1
31	VT-81	VT-81	VT-81	VT-81	VT-81	Rubber gland	1
32	VT-156	VT-156	VT-156	VT-156	VT-156	Gauze filter	1
33	VT-2512	VT-2512	VT-2512	VT-2512	VT-2512	Q/R coupling	1
34	VT-2273	VT-2273	VT-2273	VT-2273	VT-2273	O ring	2
35	VT-2261	VT-2261	VT-2261	VT-2261	VT-2261	Handle shaft	1
37	VT-2260	VT-2260	VT-2260	VT-2260	VT-2260	Twist grip	1
38	VT-16042	VT-16042	VT-16042	VT-16042	VT-16042	Adapter	1
39	VT-10270	VT-10270	VT-10270	VT-10270	VT-10270	Lubricator	1
40	VT-10289	VT-10289	VT-10289	VT-10289	VT-10289	Lubricator tube	1
41	VT-10273	VT-10273	VT-10273	VT-10273	VT-10273	Rubber ring	1
42	VT-10271	VT-10271	VT-10271	VT-10271	VT-10271	Lubricator body	1
43	VT-2524	VT-2524	VT-2524	VT-2524	VT-2524	O ring	1
44	VT-2265	VT-2265	VT-2265	VT-2265	VT-2265	Oil filler screw	1
45	VT-2525	VT-2525	VT-2525	VT-2525	VT-2525	O ring	1
46	VT-2520	VT-2520	VT-2520	VT-2520	VT-2520	Felt	9
47	VT-2521	VT-2521	VT-2521	VT-2521	VT-2521	Bleed wire	1

*Inlet and exhaust hose please state lengths required, i.e. 2 metres, 4 metres or 6 metres.

V635 – V675 PARTS DIAGRAM

